

3. Door Opening/Closing Operation

1. Key unlocking

Locate the corresponding keyhole position on the door, then insert the key and turn it clockwise to open the door


2. Closing operation

Push the door into place and turn the key counter-clockwise to close the door.

4. Installation Notes

The product with predrilled mounting holes for easy fixing to a floor or wall with included expansion bolts.

For the sake of safety, please be sure to fix the cabinet on a solid concrete wall.



Installation layout

5.Common faults and troubleshooting

Symptoms	Cause of failure	Method of exclusion
The emergency key cannot be inserted or removed	Foreign object in the keyhole The key is not turned to the limit	Remove foreign matter from keyhole Please reinsert in the correct way

6. Precautions for Use

1.Do not put the user's manual, spare keys in the box, they should be stored in other safe place.

2.Keep away from direct sunlight and heat sources , and prevent the product from falling from high altitude. Keep it in a safe place.

WARRANTY CARD

Thank you for your purchase of our products. The interests of customers who purchase our products will be protected. For any malfunction due to product quality problems, please contact authorized local dealers or service centers with this receipt and the warranty card.

Warranty terms:

- For product failures occur under normal operating circumstances, free of charge repair and spare parts replacement service shall be provided by our company within one year commencing from date of purchase.
- Customers are required to present this warranty card and the original purchase invoice to our company upon request for warranty service. This warranty card shall be valid only after the following form is filled out in details and affixed with official seal of the dealer.
- No free of charge repair service shall be provided in the event of any of the following circumstances:

- (1)Expiration of the warranty period;
- (2)Damages caused by improper use, maintenance or storage not in accordance with the requirements of the user manual;
- (3)Failure or damage resulting from unauthorized disassembly, repair or modification;
- (4)Failure or damage caused by force majeure;
- (5)Wear parts or accessories.

This warranty card is being delivered with the product, one card for one product. Please keep this warranty card in proper condition for free warranty service. There is no replacement if lost.

Date of Purchase: ____ Y ____ M ____ D

WARRANTY CARD

Product Information	Product Name		Serial Number		
	Product Model Number		Manufacturing Date		
Customer Information	Company Name		Contact		
	Address		Phone		
Sales Information	Dealer Name		Contact		
	Address		Phone		
	Date of Purchase		Invoice No		
Maintenance Record	Description of Malfunction	Maintenance Results	Customer Signature	Maintenance Technician Signature	Maintenance Date

This copy shall be cut along the dotted line and kept by the dealer.

WARRANTY CARD

Product Information	Product Name		Serial Number		
	Product Model Number		Manufacturing Date		
Customer Information	Company Name		Contact		
	Address		Phone		
Sales Information	Dealer Name		Contact		
	Address		Phone		
	Date of Purchase		Invoice No		
Maintenance Record	Description of Malfunction	Maintenance Results	Customer Signature	Maintenance Technician Signature	Maintenance Date