
LOCKS	NORTH
-------	-------

Product Code:	
Number:	

User Manual

DIGITAL SAFE



DELI GROUP CO, LTD.

Deli Industrial Zone, Ninghai County, Ningbo City, Zhejiang Province,China serviceglobal@nbdeli.com www.deliworld.com Made in China



KEEP FOR FUTURE USE Version: 1.0

Version: 1.0 Date: 02-2025

Contents

1. Unboxing		1
2. Product Schematic		2
3. initial Use		3
4.Password Setup		3
5. Door opening and closing operati	ons	3
6. Alarm instructions		4
7. Installation instructions		4


INTELLIGENT ELECTRONIC SAFE

Please do not keep emergency keys in your safe!


Thank you for choosing our products! You've taken an important step in organizing and protecting your most valued possessions. Every seres of our safes is professionally made and designed to provide safety. Please take time to read and familiarize yourself with the proper operating procedures of your new safe presented on the following pages again, thank you for choosing our products!

After opening the packaging box, please confirm whether the product appearance is intact and check off all accessores. in case of any loss or damage, please contact the dealer!


1. Unboxing



2. Product Schematic



Schematic drawing of case



Schematic drawing of control panel

-2-

3. initial Use

1. After placing the box, open the lock cover first, use the key to open the door, and install four AA batteries into the battery compartment on the back of the door.

2.For convenience, please store the user manual and keys in a secure place, do not inside the box.

4.Password Setup

1. Open the battery compartment cover on the back of the door, press the reset button once, and when the yellow light is on, you can start setting the password.

2.The password length is 3-8 digits. After entering the password, press the "A" or "B" key to confrm. Hearing "beep" twice indicates successful entry. If the yellow light blinks and you hear "beep" three times, the password entry is invalid and press the settings key again.

5. Door opening and closing operations

1. Enter the correct password, and after entering the password, press the "A"or "B" key to confrm. Hearng "beep" twice, the green light will be on, indicating successful entry. Turn the handle to open the door. If the yellow light blinks and you hear "beep" three times, the password is incorrect and needs to be retried.

2. The default factory password is 159

-3-

6. Alarm instructions

1. Self-locking due to incorrect password input

If three consecutive incorrect passwords are entered, the system will sound an alarm, and the electronic panel will lock for 20 seconds, during which the electronic panel cannot be operated. If three consecutive incorrect passwords are entered again, the system will sound an alarm, and the electronic panel will lock for 5 minutes, during which the electronic panel cannot be operated.

2. Low Battery Voltage Alarm

If the battery voltage is low, a red indicator light will illuminate on the electronic panel to remind you to replace the batteres.

7. Installation instructions

Fix the safe in the place which is not easy to move.

Drill holes for expansion bolts (or clamping screws) in the right place.

Turn the expansion bolts counter clockwise to separate.

Use the expansion bolts (or clamping screws) to secure the case to the wall or floor.

Make sure the case is mounted in place as required and then tighten all screws.

CAUTION: Use the expansion bolt when there is a concrete wall surface. Use the clamping screw when there is a wooden wall surface.

PRODUCT WARRANTY CARD

Product Informa-	Product Name				Serie	al Number				
tion	Product Model				Man Date	ufacturing I				
Customer Informa-	Company Name						Contact	Person		
tion .	Address						Contact I	Number		
	Distributor Name						Contact	Person		
Sales Informa- tion	Address						Contact I	Number		
	Sales Date						Invoice N	Number		
	Fault Condition		Repair Result			Customer Signature		Technician Signature		Date
Repair Record										

Oeli DELI GROUP CO., LTD.

Cut this copy along the dotted line and keep it in the custody of the dealer

Informa- tion	Fault Condition		Repair Result Custom		stomer Signature	mer Signature Technic		Date
	Sales Date				Invoice N	umber		
	Address				Contact N	lumber		
tion	Distributor Name				Contact F	erson		
	Address					Contact Number		
Customer Informa-	Company Name				Contact F	Person		
tion	Product Model			Manufactur Date	ing			
Product Informa-	Product Name			Serial Numb	per			