
Product Code: Number:

LOCKSWORTH

User Manual

Cash Safe Box



DELI GROUP CO, LTD.

Deli Industrial Zone, Ninghoi County, Ningbo City, Zhejiang Province,China serviceglobal@nbdeli.com www.deliworld.com Made in China



KEEP FOR FUTURE USE Version: 1.0

Version: 1.0 Date: 01-2025

Password Lock Instruction

1.Initial password:000

2.how to setup password:

- ①.Set the above key to "B"
- ②.Change the figures to set your password
- 3.Set the above key to "A",then it is over.

3.Pls record the password to avoid if you forget the password

WARRANTY CARD

Thank you for your purchase of our products. The interests of customers who purchase our products will be protected. For any malfunction due to product quality problems, please contact authorized local dealers or service centers with this receipt and the warranty card.

Warranty terms:

1. For product failures occur under normal operating circumstances, free of charge repair and spare parts replacement service shall be provided by our company within one year commencing from date of purchase.

2.Customers are required to present this warranty card and the original purchase invoice to our company upon request for warranty service. This warranty card shall be valid only after the following form is filed out in details and affixed with official seal of the dealer.

3.No free of charge repair service shall be provided in the event of any of the following circumstances:

(1)Expiration of the warranty period;

(2)Damages caused by improper use, maintenance or storage not in accordance with the requirements of the user manual;

(3)Failure or damage resulting from unauthorized disassembly, repair or modification;

(4)Failure or damage caused by force majeure;

(5)Wear parts or accessories.

This warranty card is being delivered with the product, one card for one product. Please keep this warranty card in proper condition for free warranty service. There is no replacement if lost.

Purchase Date:	(Year)	(Month)	(Day)
ruiciiuse bute.	(1001)	(1-1011(11)	(Dug)

— PRODUCT WARRANTY CARD —

Product Informa-	Product Name				Seri	al Number				
tion	Product Model Number				Man Date	ufacturing				
Customer Informa	Company Name						Cont	act		
tion -	Address						Pho	ne		
Sales Informa- tion	Dealer Name						Cont	act		
	Address						Pho	ne		
	Date of Purchase						Invoic	e No.		
Mainte- n a n c e Record	Description of Malfunction		Maintenance Results		3	Customer Signature		Maintenance Technician Signature		Maintenance Date

deli group co., LTD.

Cut this copy along the dotted line and keep it in the custody of the dealer

Product	Product Name			Serial Nu	mber				
Informa- tion	Product Model Number			Manufac Date	turing				
Customer	Company Name					Conto	act		
tion	Address					Phone			
Sales Informa- tion	Dealer Name					Contact			
	Address					Phone			
	Date of Purchase					Invoice	No.		
	Description of Malfunction		Maintenance Results C		Custom			iance ian Signature	Maintenance Date
Mainte-									
Record									