


Product Code: _____

Number: _____

User Manual

Password Safe Series



DELI GROUP CO, LTD.
Deli Industrial Zone, Ninghai County,
Ningbo City, Zhejiang Province, China
serviceglobal@nbdeli.com
www.deliworld.com Made in China




**KEEP FOR
FUTURE USE**
Version: 1.0
Date: 04-2025

Contents


I. Product Unpacking	1
II. Product Diagram	1
III. First Use	2
IV. Password Setting	2
V. Opening And Closing Door Operation	2
VI. Emergency Opening	2
VII. Replacement of batteries	3
VIII. Installation Instructions	3
IX. Usage Precautions	3
X. Common Faults and Troubleshooting Methods	4
XI. After-sales Service	5

Welcome to use our series of safes, cabinets, and storage boxes.
Please read this instruction manual carefully before use and operate
according to the instructions.

I. Product Unpacking



II. Product Diagram



III. First Us

1. After placing the box, insert the emergency key into the lock hole and turn it clockwise, then turn the handle clockwise to open the box door, and install the 4 Pieces of AA batteries into the battery box behind the box door.
2. For ease of use, please store the manual and key in a safe place, not inside the box.

IV. Password Setting

1. The factory password is 159
2. Open the door, press the [SET], 'beep' two sound, yellow light, please set 3-8 password, after entering the password, press the [#] to confirm.

V. Opening And Closing Door Operation

1. Open the door: enter the correct password, press the '#' to confirm, 'beep' two sounds, the green indicator light, please turn the knob to open the door within 5 seconds.
2. If you input the wrong password three times in a row, it will be locked for 20 seconds (you will not be able to input the password in the locked state), and if you input the wrong password three times in a row after 20 seconds, it will be locked for 5 minutes, during which you cannot operate the panel.
3. Close the door: close the door and turn the handle anti-clockwise to lock the door.

VI. Emergency Opening


When the electronic system malfunctions or the code is forgotten, please use the key to open the door in the same way as the first time.

VII. Replacement of batteries

1. The product opens the door, when the battery power is insufficient, the red indicator light flashes, at the same time, the buzzer 'beep' five times, at this time, please replace the battery in time

VIII. Installation Instructions

Always fix the cabinet to a solid concrete wall for safe keeping.



Installation Diagram

IX. Usage Precautions

1. Do not put the user manual, emergency key in the box, should be stored in other safe place.
2. The battery should be taken out to prevent the leakage of liquid from damaging the electronic system if the product is left unused for a long time.
3. For safety reasons, please be sure to fix the cabinet on a solid concrete
4. Do not store too much cash and valuables when unattended or without a remote alarm device.

X. Common Faults and Troubleshooting Methods

Fault Phenomenon	Fault Cause	Method of exclusion
Pressing the numeric keys to enter the password does not respond	The battery is dead	Open the door with the key and replace the battery
	Battery polarity reversed	Insert the batteries in the correct way
	Fault PCB	Please contact the maintenance department
The emergency key cannot be inserted in or removed	Foreign matters in the keyhole	Remove foreign matters from the keyhole
	The key does not turn to the limit position	Please reinsert in the correct way
Electronic combination lock has been opened, the door can not be opened	Faulty electronic panel or jammed door mechanism	Please contact the maintenance department
The alarm does not sound	The battery is dead	Replace the battery
	Battery polarity reversed	Insert the batteries in the correct way

XI. After-sales Service

Dear user,

Thank you for purchasing our company's product. To ensure your satisfaction and benefits, if your product malfunctions due to quality issues, you can contact your local dealer or authorized service center with your warranty card.

Warranty Instructions:

1. Our company provides free warranty services, including repairs and parts replacement, for any malfunction that occurs under normal use within one year from the date of purchase;
 2. This warranty card and the purchase invoice are the proof of our after-sales service to customers. This card must be filled out with the required information in detail and stamped by the dealer to be valid.
 3. In the following circumstances, free warranty service is not applicable, and paid repairs will be required:
 - ① The product is beyond the warranty period.
 - ② The product is damaged due to improper use, maintenance, or storage that does not comply with the product's user manual.
 - ③ The product malfunction or damage is caused by force majeure.
 - ④ Wearable parts and accompanying accessories.
 - ⑤ The product is damaged due to excessive twisting or improper use.
- This warranty card is issued together with the product, with one card for each product. To ensure that you can fully enjoy the rights to our free warranty service, please keep this card properly. No replacement will be provided for lost cards.

Purchase Date: _____ (Year) _____ (Month) _____ (Day)

PRODUCT WARRANTY CARD

Product Information	Product Name		Serial Number		
	Product Model		Manufacturing Date		
Customer Information	Company Name			Contact Person	
	Address			Contact Number	
Sales Information	Distributor Name			Contact Person	
	Address			Contact Number	
	Sales Date			Invoice Number	
Repair Record	Fault Condition	Repair Result	Customer Signature	Technician Signature	Date

deli DELI GROUP CO., LTD.

Cut this copy along the dotted line and keep it in the custody of the dealer

Product Information	Product Name		Serial Number		
	Product Model		Manufacturing Date		
Customer Information	Company Name			Contact Person	
	Address			Contact Number	
Sales Information	Distributor Name			Contact Person	
	Address			Contact Number	
	Sales Date			Invoice Number	
Repair Record	Fault Condition	Repair Result	Customer Signature	Technician Signature	Date